

Clip-On PowerStrips

ideas for space









- 1. Clip the PowerStrip flat J-Hook onto the middle of the selected top wire.
- 2. 1/2 to 2/3 way down the wire grid, attach the second flat J-hook to the middle of the wire grid (even with the top J-hook) and remove the adhesive liner.
- 3. Press PowerStrip firmly onto the second flat J-hook until tightly secured.
- 4. Place peg hook with molded scan plate for UPC label in top holes and add remaining peg hooks to fit products or follow POG.
- 5. Add H.E.B. Reusable Freezer Bags to peg hooks as shown.











1950 Austin Drive • Troy, Michigan 48083 800-992-5233 • 248-589-3272 • Fax 248-589-1535 Email: hq@tmshea.com • www.tmshea.com



































